

# MONOCOAT OIL PLUS APPLICATION

## Furniture & Fixtures

### FEATURES:

**Rubio Monocoat Oil Plus** colors and protects your wood in one layer. Unlike traditional hardwax oils, **Monocoat Oil Plus** will connect with wood fibers by means of a molecular reaction, a result of which a durable protection is obtained. This molecular connection enables **Monocoat Oil Plus** to embed in the surface's upper microns immediately. The wood fibers can only combine with a certain amount of oil. Oil, which has not reacted, does not adhere and needs to be removed.

- 100 % VOC-FREE!
- No starting marks or overlaps
- 34 standard colors
- For use on all kinds of wood (solid, veneer, MDF, reclaimed, etc...)
- Durable protection, highly resistant to wear
- Resistant to heat up to 212 °F
- Water-resistant: (suited for kitchens and baths)

### MAINTENANCE:

After treatment with **Monocoat Oil Plus**, the finish requires 3 weeks to harden completely. After 3 weeks, the finish can be maintained using maintenance products from the **Monocoat** range.

### CONSUMPTION:

Pure Oil - 1 liter, up to 500 sq. ft.  
Color Oil - 1 liter, up to 400 sq. ft

### INSTRUCTIONS:

- 1) If you are preparing finished surfaces, all previous finishes must be removed. Please note that the higher grit of sanding material used, the lighter the color of the oil will be.
- 2) Remove any dust with a vacuum cleaner and clean cloth before proceeding. If you are finishing an exotic wood species (Brazilian Cherry, Santos Mahogany, Merbau, etc.) it is recommended to clean the wood with **Monocoat Raw Wood Cleaner** prior to oiling.
- 3) Apply **Monocoat Oil Plus** with a cotton cloth, brush, or soft sponge.
- 4) Remove any excess oil 10 minutes after application with a clean cloth. Change the cloth when it is saturated. Continue this until all the excess oil is removed.  
**This is very important as excess oil can increase the drying period.**
- 5) Repeat step 3) and 4) until the entire surface is done and all excess oil is removed. If a silk-matte appearance is desired, polish the surface with a polishing machine and lambs wool.
- 6) Try to ventilate as much as possible during working and drying periods for a faster drying time.

**Oil-saturated cloths can spontaneously combust and must therefore be burned, placed in water or kept in a lidded-sealed metal container.**